



Installation Reference

This installation reference is designed to help customers. It is important that the installation steps are followed. If failure to proceed using these steps, it may hinder the integrity of the adhesive. Below shows a checklist of items needed to proceed the installation steps.

Recommended materials but not limited to:

- Broom, vacuum, or air hose
- Carpenter's Knife
- Other Stain/ Adhesive removers
- Smooth faced roller
- 91+% Alcohol
- Acetone



Installation Steps:

1. Clean all surfaces of dirt, sand, dust, etc. with either a vacuum, broom, brush, or air hose.
2. Clean all surfaces of adhesive, water, paper, dirt, stains using (recommended products) Acetone, 91+% Rubbing Alcohol, Goo-Gone, and Adhesive remover.
3. Final cleaning, use at least 91% Rubbing alcohol a final pass to ensure the surface is clean and has no moisture / chemical on the surface.
4. Take the Pads out of the box/shipment.

5. Lay pads in designated areas before installation to ensure the best fit in the area.
6. *RECOMMENDED*: Start from one area and only go one direction. Example: Bow to Stern, or Port to Starboard. This will ensure that all your spacing is perfect and aligned correctly.
7. Take a carpenter's knife and CUT ONLY the paper backing of the pad and peel and crease about 2" of the paper backing to each side. The result you will have is a sticky center of the pad showing to ensure the correct alignment without shifting.
8. Place the pad in the correct orientation and alignment. Once the pad is aligned, apply force on the top side of the sticky area.
9. Hold pad down on the topside in the center and reach and grab paper tab created in step #8.
10. Slowly peel paper backing while following with the other hand and pressing the pad down from the top side.
11. After one side is done, do the same for the other side.
12. After the pad is completely stuck down, go around edges with fingertips or a circular roller tool to press down the pads.
13. Repeat steps #8 to #13 to all pads.
14. After all pads are stuck down, go across pads with at least 15lbs of force on all surfaces. Can use either a smooth faced roller or hands, this will ensure the adhesive sticks to the surface.