



Easypoxy

Modern Polyurethane Enamel

TECHNICAL BULLETIN 220 5/13

- Exceptionally easy one-part application
- Long lasting, durable polyurethane finish
- Fortified with advanced ultraviolet filters
- Provides superior gloss retention



Easypoxy is a modern one-part polyurethane topside and deck enamel. The addition of silicone provides for a brilliant shine and easy brushability. Advanced ultraviolet filters enhance the superior gloss retention and durability of polyurethane. The result is a topside finish that produces a lasting gelcoat-like brilliance with a minimum of effort. For a semi-gloss finish for decks and interiors use #3106 Semi-Gloss White or simply add Satin Additive # 9080 to any Easypoxy color for a custom satin look. For non-skid decks, Pettit's EZ-Decks Nonskid

Enamels are designed to match corresponding Easypoxy colors or Skidless Compound # 9900 may be added prior to application. EZ-Prime # 6149 should be used as a base coat whenever the surface to be painted is aged, cracked, checked, pitted, or in any way less than smooth. When using on bare wood, seal with EZ WoodSealer #2018 to provide water resistance and dry rot protection.

PHYSICAL DATA	APPLICATION DATA	ASSOCIATED PRODUCTS																																		
<p>VEHICLE TYPE: Oil modified polyurethane</p> <p>FINISH: High-gloss</p> <p>COLORS: See Pettit color chart</p> <table border="0"> <tr> <td>3175 Gloss White</td> <td>3106 Semi-Gloss White</td> </tr> <tr> <td>3108 Off White</td> <td>3213 Blue Ice</td> </tr> <tr> <td>3229 Bikini Blue</td> <td>3232 Teal Blue</td> </tr> <tr> <td>3237 Electric Blue</td> <td>3248 Ocean Blue</td> </tr> <tr> <td>3348 Jade Green</td> <td>3350 Kelly Green</td> </tr> <tr> <td>3415 Sunflower Yellow</td> <td>3510 Bight Work Brown</td> </tr> <tr> <td>3518 Sandtone</td> <td>3520 Grand Banks Beige</td> </tr> <tr> <td>3624 Bright Red</td> <td>3626 Burgundy</td> </tr> <tr> <td>3705 Mist Gray</td> <td>3706 Pearl Gray</td> </tr> <tr> <td>3711 Platinum</td> <td>3720 Dark Gray</td> </tr> <tr> <td>3801 Black</td> <td></td> </tr> </table> <p>COMPONENTS: 1</p> <p>CURING MECHANISM: Air dry/oxidation</p> <p>SOLIDS (theoretical): By weight...62.0 +/- 7% - By volume...49.6 +/- 2%</p> <p>COVERAGE: 600 sq. ft/gal.</p> <p>VOC: 394 g/l for White (other colors will vary slightly)</p> <p>FLASH POINT: 113°F for White (other colors will vary slightly)</p>	3175 Gloss White	3106 Semi-Gloss White	3108 Off White	3213 Blue Ice	3229 Bikini Blue	3232 Teal Blue	3237 Electric Blue	3248 Ocean Blue	3348 Jade Green	3350 Kelly Green	3415 Sunflower Yellow	3510 Bight Work Brown	3518 Sandtone	3520 Grand Banks Beige	3624 Bright Red	3626 Burgundy	3705 Mist Gray	3706 Pearl Gray	3711 Platinum	3720 Dark Gray	3801 Black		<p>METHOD: Brush, roller, or spray</p> <p>NUMBER OF COATS: 2 minimum</p> <p>DRY FILM THICKNESS PER COAT: 1.5 mils (3 wet mils)</p> <p>APPLICATION TEMP: 50° F. Min. / 90°F. Max.</p> <p>APPLICATION HUMIDITY: 0% Min. / 90% Max.</p> <p>DRY TIME (HOURS):</p> <table border="0"> <tr> <td></td> <td>To Touch</td> <td>To Recoat</td> </tr> <tr> <td>90°F</td> <td>1-1/2</td> <td>8</td> </tr> <tr> <td>70°F</td> <td>3</td> <td>16</td> </tr> <tr> <td>50°F</td> <td>6</td> <td>24</td> </tr> </table> <p>THINNER: 120 Brushing Thinner 121 Spraying Thinner</p> <p>CLEANER: 120 Brushing Thinner</p>		To Touch	To Recoat	90°F	1-1/2	8	70°F	3	16	50°F	6	24	<p>D-95 Fiberglass Dewaxer</p> <p>92 Bio-Blue Hull Surface Prep</p> <p>6149 EZ-Prime</p> <p>6455/044 Metal Primer Pack</p> <p>6980 Rustlok Primer</p> <p>6627 Tie Coat Primer</p> <p>2018 Clear Sealer</p> <p>9080 Easypoxy Satin Additive</p> <p>9900 Skidless Compound</p> <p>7050 EZ-Fair Compound</p> <p>120 Brushing Thinner</p> <p>121 Spraying Thinner</p>
3175 Gloss White	3106 Semi-Gloss White																																			
3108 Off White	3213 Blue Ice																																			
3229 Bikini Blue	3232 Teal Blue																																			
3237 Electric Blue	3248 Ocean Blue																																			
3348 Jade Green	3350 Kelly Green																																			
3415 Sunflower Yellow	3510 Bight Work Brown																																			
3518 Sandtone	3520 Grand Banks Beige																																			
3624 Bright Red	3626 Burgundy																																			
3705 Mist Gray	3706 Pearl Gray																																			
3711 Platinum	3720 Dark Gray																																			
3801 Black																																				
	To Touch	To Recoat																																		
90°F	1-1/2	8																																		
70°F	3	16																																		
50°F	6	24																																		



APPLICATION INFORMATION

Stir thoroughly before use. Easyepoxy may be applied by brush, roller, conventional or airless spray. For brush or roller application apply without thinning although in hot weather 5-10% Pettit 120 Brushing Thinner may be added to maintain a wet edge. For best results on large, smooth surfaces roll out using a short nap roller followed immediately by leveling off with the tip of a brush. For conventional spray application thin 15-20% with Pettit 121 Spraying Thinner. Apply one, thin even coat per day. After an overnight dry, lightly sand with 220 grit sandpaper and apply a second coat. Applying two or more coats in one day or applying excessively heavy films (greater than 4 wet mils) will lead to insufficient through drying of the paint and will yield soft paint films. For airless spray application thin up to 5% with Pettit 121 Spraying Thinner. Utilize a .011-.015 inch diameter tip for application. Do not apply Easyepoxy on extremely humid days (90°+ RH) or when rain is threatening. Do not apply in the late afternoon when working outdoors as the wet film may be adversely affected by dew. When working in cooler temperatures be sure the air and surface temperatures will remain at or above 50°F for at least 8 hours after application.

Surface Preparation: Coating performance, in general, is proportional to the degree of surface preparation. Follow recommendations carefully, avoiding shortcuts. Inadequate preparation of surfaces will virtually assure inadequate coating performance. Surface must be free of dirt, loose paint, rust, oil, grease, wax, soap and any other foreign matter. Clean painted areas by washing with a solution of 2 cups household ammonia per gallon of water and rinse well. Remove existing mildew with household bleach instead of ammonia.

SYSTEMS

Bare Wood: Sand surface smooth with 80-120 grit sandpaper, then solvent clean with Pettit 120 Thinner to remove residue. Fill all screw heads or small holes with 7050 EZ-Fair Epoxy Fairing Compound; sand flush and solvent clean with Pettit 120 Thinner. Apply a coat of 2018 EZ WoodSealer to penetrate and seal the porous grain. Follow with one or two coats of 6149 EZ Prime until an evenly smooth base condition is reached; sand each coat with 80-120 grit sandpaper and solvent clean with Pettit 120 Thinner. Proceed with the first finish coat of Easyepoxy.

Bare wood that has been epoxied must be thoroughly scrubbed with an ammonia/water solution then sanded with 120 grit sandpaper and solvent cleaned with Pettit 120 Thinner. Follow with a coat of 6149 EZ Prime to smooth the surface and provide a uniform base. Sand well and solvent clean with Pettit 120 Thinner, then proceed with the first coat of Easyepoxy.

Bare Steel: Surface must be cleaned to a bright finish by sandblasting or grinding; remove blast residue. Immediately apply one coat of 6980 Rustlok Primer; allow to dry until tacky. If surface is rough, apply a coat of 6627 Tie-Coat Primer; sand well and solvent clean with Pettit 120 Thinner. Repeat application as needed until a smooth, uniform base is reached. Proceed with the first coat of Easyepoxy.

Bare Aluminum: Wipe the surface free of oil and grease with Pettit 120 Thinner. Remove oxidation and etch the surface with medium grit emery cloth; remove sanding residue. Apply one thin "wet" coat of 6455/044 Metal Primer; allow to dry at least two hours. Proceed with the first coat of Easyepoxy. 6149 EZ Prime can be used over the 6455/044 Metal Primer for smoothing surfaces if desired.

Bare Fiberglass: The entire surface to be painted regardless of age must be thoroughly washed with 120 thinner or 92 Bio-Blue to remove all traces of mold release agents and wax. Sand the gel coat with 80 to 120 grit sandpaper to a dull, frosty appearance, solvent clean with Pettit 120 Thinner to remove residue. If the surface is in excellent condition, proceed with the first finish coat of Easyepoxy.

If the surface is rough or imperfections exist, it will have to be repaired. Fill all nicks and gouges with 7050 EZ-Fair Epoxy Fairing Compound; sand flush when hard, then solvent clean. Follow with a coat of 6149 EZ Prime to smooth the surface and provide a uniform base; sand well and solvent clean. Proceed with the first finish coat of Easyepoxy.

Painted Surfaces: Clean painted areas by washing with a solution of two cups household ammonia per gallon of water and rinse well. Remove existing mildew with household bleach instead of ammonia. Never mix bleach and ammonia. If the old paint is an oil-based enamel or polyurethane, and is in good, sound condition, sand it thoroughly smooth with 150 grit sandpaper, solvent clean to remove residue with Pettit 120 Thinner, then proceed with the first coat of Easyepoxy. If the old oil-base or polyurethane paint contained a non-skid material, scrub the non-skid service with Pettit # 92 Bio-Blue Hull Surface Prep using a stiff bristle brush. Thoroughly rinse the surface and allow to dry, then apply two coats of Easyepoxy. If the old paint is a latex or water-based paint, or is in poor condition, remove it with a paint and varnish remover or by sanding. Proceed with instructions for the appropriate bare surface system.

Non-Skid Decks: To provide a safe, slip-proof texture on decks, add Pettit 9900 Skidless Compound to the mixed Easyepoxy. Stir mixture continuously to insure compound is thoroughly dispersed and remains in suspension. A minimum of two coats are recommended, following the appropriate application system. Alternatively, apply a coat of Easyepoxy (without 9900 Skidless Compound) to all areas requiring a non-skid surface, then sprinkle or broadcast the 9900 Skidless Compound into the wet Easyepoxy. After drying overnight carefully brush-out all loose Skidless Compound and apply another thin, even coat of Easyepoxy to the surface. For decks which have a pre-molded, non-skid embossment, scrub the non-skid surface with Pettit # 92 Bio-Blue Hull Surface Prep using a stiff bristle brush or wash the surface with 95 Fiberglass Dewaxer. Abrade area thoroughly with bronze wool then solvent clean with Pettit 120 Thinner to remove residue. Apply two coats of Easyepoxy adding 9900 Skidless Compound to the mixture if an improved non-skid texture is desired.